

**INSTALLATION SPECIFICATION
FOR ANYWHERE BASIC COLLECTION**

**WHEN INSTALLING, WE RECOMMEND USING A PROFESSIONAL INSTALLER
IT IS IMPORTANT TO FOLLOW CRI-104 GUIDELINES.**

**IT IS RECOMMENDED THE MATERIAL BE ACCLIMATED FOR 24 HOURS IN THE ROOM WHERE
IT WILL BE INSTALLED. FLOOR TEMPERATURE SHOULD BE MAINTAINED AT
60-65 DEGREES BEFORE, DURING AND 72 HOURS AFTER INSTALLATION.**

**AMBIENT HUMIDITY LEVEL SHOULD NOT EXCEED 75%
THE SUB-FLOOR SHOULD BE DRY, SMOOTH, CLEAN AND SOUND
ALL SUBSTRATES AND CONDITIONS MUST COMPLY WITH INDUSTRY STANDARDS
(SUCH AS ASTM F710)**

APPROVED INSTALLATION METHODS;

- WE RECOMMENDS DIRECT GLUE-DOWN INSTALLATION FOR BEST RESULTS
- STRETCH-IN INSTALLATION IS ALSO POSSIBLE

SEAMS

- WE RECOMMEND SIDE SEAMS ONLY, AVOID END SEAMS
- CUTTING SHOULD BE DONE FROM THE TOP WITH A SHARP KNIFE.
- BOTH STRIPS SHOULD BE CUT SEPARATELY, DO NOT DOUBLE CUT
- ADJOINING STRIPS SHOULD BE INSTALLED IN THE SAME DYE LOT AND DIRECTION
- FOR A GOOD SEAM AND TO AVOID FRAYING, BOTH EDGES SHOULD BE TREATED WITH SEAM SEALER BEFORE JOINING.

DIRECT GLUE-DOWN INSTALLATION

- REQUIRES THE PROPER USE OF A 1/8 X 1/8 X 1/8 V NOTCHED TROWEL
- USE PREMIUM MULTI-PURPOSE ADHESIVE FOR INDOOR INSTALLATION
- WE RECOMMEND MAPEI G19 ULTRABOND 2-PART EPOXY FOR OUTDOOR
- ALWAYS FOLLOW DIRECTIONS PROVIDED BY THE ADHESIVE MANUFACTURER

ANYWHERE BASIC CAN ALSO BE INSTALLED TRADITIONALLY OVER PAD ON TACK-STRIP

- SEAMS MUST BE JOINED WITH A STRONG HOT MELT SEAM TAPE
- THE USE OF SHORT PIN TACK STRIP IS RECOMMENDED

LOOSE FITTING, EVEN IN SMALL ROOMS, IS NOT RECOMMENDED

We recommends professional installers, be familiar with the CRI-104, minimum guidelines for installing commercial carpeting. We also recommend installers with experience in flat-weave carpeting.