

BOLON INSTALLATION INSTRUCTIONS

RECOMMENDED ADHESIVES

- Acrylic high-quality glues for low to moderate levels of traffic, i.e. Henkel K188E
- Polyurethane compound glues for high levels of traffic, i.e. Henkel R710
- Water-resistant adhesive for humid and wet areas

LAYING

Bolon flooring should be installed by professional carpet fitters. Bolon flooring is laid by gluing onto any dry and clean surface. This must be done at a temperature of 15 degrees Celsius or above. Always follow the instructions of the adhesive producer!

1. The batch numbers of individual colors should not be mixed on installation.
 2. Before laying the material must adapt to room temperature for at least 24 hours. Cut the length allowing 5-10 cm over measure and let it lay unrolled at least overnight.
 3. Bolon flooring is delivered in rolls approx. 2 meters in width. The flooring should be rolled out in the direction of the length of the room. This will improve the appearance of the flooring and simplify the maintenance. When planning the installation remember to avoid seams across the flooring.
 4. Draw a line 1.94 m away from the wall. Spread the adhesive out evenly. Stop 15 cm from the line.
 5. Allow the adhesive to aerate. Lay out the flooring and follow the line's outer edge carefully. Smooth out any bubbles so that the flooring is even.
 6. Always install in the same direction.
 7. Repeat the same procedure (5 + 6) with the next length and begin by drawing a line 1.94 m from the previous length, so that the lengths overlap by approx. 4 cm.
 8. Cut through both lengths in the direction of the seam. Remove the surplus pieces.
 9. Lift up the two lengths and glue. Put the lengths together and ensure that they are laying edge to edge. The joints should be invisible (with the exception of the Coco Rail designs, in order to maintain its natural look).
 10. All seams must be cold-welded using the Werner-Muller-GmbH type A PVC-cold-welding technique or a similar technique.
- In domestic locations the flooring can be loose laid up to 25 meters squared, using double-faced tape.
 - To prevent damage on all floorings, don't drag furniture or other sharp objects along the flooring; lift when moving.
 - Bolon flooring can be used with under floor heating systems and with underlay to provide softer flooring.

INSTALLING ON STAIRS

For stairs Bolon recommends the use of front edge moldings to increase wear on the stair edges.

INSTALLATION INSTRUCTIONS FOR BOLON WITHOUT BACKING

Allow the adhesive to dry until tacky and just enough so that its adhesive properties remain. The flooring should be flattened with a soft brush, not a roller. The adhesive must not penetrate the small holes in the weave structure of the flooring. Too much adhesive or insufficient aeration can cause visible rings several weeks after laying. These rings cannot be removed.

- - - - -

Always test the adhesive on a small area first.